



# ENFORCER RELEASABLE PLATE CARRIER ASSEMBLY GUIDE

## PARTS



**BACK PANEL**

**FRONT PANEL  
(WITH STRAPS)**




**CUMMERBUND (2X PIECE)**



**SHOULDER  
PADS (2X PIECE)**

**VELCRO LOOPS  
(1 USE, 1 SPARE)**



**PULL CORD**



**01- INSERT PULL CORD INTO SHOULDER STRAP SLEEVE ON THE OPPOSITE SIDE OF THE HAND YOU WANT TO PULL WITH. THREAD ALL THE WAY TO THE END OF THE STRAP**



**02- INSERT SHOULDER STRAP INTO BACK PANEL SLEEVE.**



**03- INSERT REMAINING SHOULDER STRAP INTO BACK PANEL**



**04- OPEN BACK PANEL AND PULL SHOULDER STRAPS THROUGH**



**05- FEED BOTTOM CONNECTOR LOOP THROUGH CUMMERBUND GROMMET OF YOUR CHOOSING. WHICH GROMMET USED WILL HELP DETERMINE THE FIT**



**06- FEED BOTTOM CONNECTOR LOOP THROUGH REMAINING CUMMERBUND GROMMET**



**07- FEED BOTTOM AND TOP CONNECTOR LOOPS THROUGH GROMMETS ON SHOULDER STRAP THAT DOES NOT HAVE THE PULL CORD.**



**08- FEED TOP AND BOTTOM LOOP CONNECTOR THROUGH GROMMETS ON STRAP WITH PULL CORD. FEED PULL CORD THROUGH CONNECTOR LOOPS TO SECURE THE STRAPS IN PLACE**



**09- TAKE REMAINING PULL CORD AND TUCK INTO MOLLE POCKET FOR SECURELY HOLDING STRAP IN PLACE**





# ENFORCER RELEASABLE PLATE CARRIER ASSEMBLY GUIDE

## PARTS



**BACK PANEL**



**FRONT PANEL  
(WITH STRAPS)**



**10- CLOSE AND SECURE THE BACK PANEL**



**11- FLIP OVER VEST TO FRONT PANEL**



**12- OPEN FRONT PANEL BY RELEASING  
BOTTOM HOOK AND LOOP TABS**



**CUMMERBUND (2X PIECE)**



**13- FOLD OVER CUMMERBUND STRAP  
AND ATTACH TO THE LOOP PANEL.  
HOW FAR IT IS FOLDED OVER WILL  
AFFECT THE FIT OF THE VEST**



**14- FOLD OVER REMAINING CUMMERBUND  
IN SIMILAR FASHION AS STEP 13**




**15- CLOSE FRONT PANEL FLAP AND  
SECURE HOOK AND LOOP TABS**



**SHOULDER  
PADS (2X PIECE)**



**VELCRO LOOPS  
(1 USE, 1 SPARE)**



**PULL CORD**



**16- PROP UP VEST FOR EASIER ACCESS  
TO THE SHOULDER STRAPS FOR  
ATTACHING THE SHOULDER PADS**



**17- OPEN UP SHOULDER PADS. WITH  
THE WIRE GUIDES FACING OUT AND  
MOLLE FACING UP, PLACE SHOULDER  
PAD OVER SHOULDER STRAP.**



**18- FOLD SHOULDER PAD UNDER  
SHOULDER STRAP AND SECURE.  
REPEAT STEP 17 WITH OPPOSITE  
SHOULDER STRAP AND PAD**